



① ZT310-X说明书\*1  
3040301-015800



② ZT250-S左后视镜\*1  
1194100-001000



③ ZT250-S右后视镜\*1  
1194100-002000



④ ZT250-SM8螺栓装饰扣\*4  
1224100-025000



⑤ ZT310-R方向把压块（自制）\*1  
1134200-005000



⑥ 外径 $\Phi 50 \times 38$ 圆柱精滤器\*1  
1050851-006000



⑦ SN 5W-40机油总成\*2  
3070100-012100



⑧ ZT310-X挡风玻璃\*1  
1224200-052000




⑨ 内六角头M6\*30螺栓  
（手把开关打紧螺栓）\*4  
1250205-031091



⑩ 十字球头M5\*30  
（右手把开关定位螺栓）\*1  
1251100-219000



⑪ 非标螺栓M6 $\times$ 12  
（304不锈钢）\*2  
1251100-101000



⑫ GB6177.1M6（环保彩）\*2  
1250303-010093



⑬ 钥匙\*2



⑭ 310PKE钥匙纽扣电池\*1  
1184200-040000



⑮ ZT310-X包围左面板标牌\*1  
1210201-393000



⑯ ZT310-X包围右面板标牌\*1  
1210201-394000



⑰ ZT250-R平衡块委外总成\*1  
1134100-029000



⑱ 后广告牌 (ZONTES升仕)\*1  
1210201-362000



⑲ ZT250-S随车工具\*1  
1274100-053000



⑳ ZT310-X尾裙中部盖板\*1  
1224200-044000